


Test Procedure for the NV890200PDR2GEVB Evaluation Board



Required Equipment

- 2 x DC voltage source
- 1 x DC electronic load
- 2 x Multimeters

Test Procedure:

- 1. Connect the test setup as shown above.
- 2. Make sure the load is not enabled.
- 3. Apply enable voltage VEN=0V. Apply an input voltage, VIN = 13.2 V. Vout should be 0V.
- 4. Apply enable voltage VEN=3V. Verify that the *output voltage is 3.3 V* +/-0.15 V.
- 5. Set up the load to 2A and enable it. Verify that the *output voltage is still 3.3 V* +/-0.15 V.
- 6. Change the input voltage to 36 V. Verify that the output voltage is 3.3 V +/-0.15 V.
- 7. Change the input voltage to 6 V. Verify that the *output voltage is 3.3 V* +/-0.15 V.
- 8. Change the input voltage to 3.9 V. Verify that the *output voltage is 0 V*.
- 9. Change the input voltage to 6 V. Verify that the *output voltage is 3.3 V* +/-0.15 V.
- 10. Apply an enable voltage VEN=0V. Vout should be 0V.
- 11.Turn off the DC sources.